

User Guide

BS-LX Audio Telephone

(on a BSX Isolating Exchange System)



Key button

This button opens the calling entrance

Optional

If green the door is physically open

Ringer mute button

Press to turn mute on or off. Red indicates muted.

Operation

1. When the phone rings pick up the handset to converse with the caller.
2. To let the person in press the key button (note this can only be used during a call).
3. If you wish to stop the phone from ringing press the ringer mute button. Press the button again to cancel (note the ringer mute button flashes red when the phone is rung, whether it is muted or not).