

# Operation Guide

## Model BS-LX Phone

PD-252 Issue 1



### Unlock button

Press to unlock the entrance.  
If the green light is on an entrance is physically open (optional).

### Mute button

Press to mute / unmute the ringer.  
Phone is muted if the red light is on permanently.  
Red light flashes when the phone is being called (even if muted).